PRODUCT DATA SHEET

DUROPROOF PPM STD

Engineered Construction Chemicals Made In Australia For Over 44 Years

SINGLE COMPONENT POLYUREA/ POLYURETHANE MEMBRANE

DESCRIPTION

DUROPROOF[™] PPM STD is a high quality, superior performance self levelling single component liquid that cures to rapidly to form a polyurea/polyurethane hybrid membrane that is tack-free, high modulus, tough, flexible and suitable for exterior use*.

FEATURES

- Single component, easy to spread.
- Combines high elongation and tensile strength for excellent toughness.
- Low odour, low VOC & complies with Green Star requirements.
- Trafficable and tack-free overnight cure
- Good abrasion and tear resistance
- Good resistance to weathering.
- Class III elongation as per AS/NZ 4858
- High build application is possible

USE AREAS

- Reinforced concrete roofs and decks
- Waterproofing external balconies, podium levels, prior to the application of a variety of surface finishes, such as tiled screeds, supported pavers, timber decking and synthetic grass.
- Light traffic installations

PACKAGING

• 20 Kg

TYPICAL PHYSICAL PROPERTIES

Appearance	Liquid, grey
Weather Resistance	Good
Solids Content , wt %	90
Tensile Strength Max.	6.6 MPa
Elongation at break	310%
Hardness	69 shore A
Clean up	Xylene
Shelf life	6 months in unopened container @ 20°C
Coverage	Wet area & non exposed: 1.25 litres/sq. m. at 1 mm dry film thickness. Exposed & light traffic: 1.5 litres/sq. m at 1.2 dry film thickness.
VOC	132 g/L

CURING: Cures within 8 hours. Re-coat within 48 hours @ 25°C & 75% RH.

Notes: DO NOT direct stick tiles to membrane. Use unbonded screed method in accordance with AS3958.1. Allow 24 hours to cure, prior to covering with surface finishes.

* For best exterior performance contact Durotech for top coats.







SUBSTRATE PREPARATION

Ensure sheet surfaces are firmly fixed to manufacturer's

directions. Surface must be free of dirt, dust, loose particles, oily contaminates, old membranes & coatings laitance, curing compounds and flaking concrete, etc. Grind, acid etch or sandblast concrete if necessary. Concrete must be a minimum strength of 20MPa and have cured a minimum of 28 days. Concrete should be fine broom finished. Surfaces must be dry with a moisture content below 5%. Fill all screw holes, cracks and voids with PU sealant. Install leak control flanges around all pipe penetrations. Build-up areas that are likely to cause ponding.

PRIMING

The preferred primer for general use is Duromix Hibuild WBE Primer. PU Primer is suitable where the condition of the concrete surface needs a primer with good penetration. Coat PU primer within 24 hrs. For wet areas where prolonged water contact is likely e.g. roof areas under pebbles, prime and completely seal the surface with Hibuild WBE before hand.

Refer to the Hibuild WBE technical data sheet for full instructions. PVC fittings should be etched primed (e.g. pink plumber's primer).

DETAILING

Apply a 10-15mm fillet of PU Sealant between all horizontal to vertical joints. Apply to all horizontal to vertical junctions, and around pipe/column penetrations. Around rain water and floor waste outlets, and over fine shrinkage cracks, apply additional DUROPROOF™ PPM STD to 0.75mm dry film thickness

DUROTECH INDUSTRIES

"This document, including any attached files, is strictly confidential and intended solely for the use of the individual or entity to which it is addressed. Durotech Industries prohibits the right to publish, copy, distribute or disclose any information contained in this document, or its attachments, by any party other than the intended recipient. If you have received this document in error please notify the sender and delete it from your system immediately, no employee or agent is authorised to conclude any binding agreement or make any representation on behalf of Durotech Industries. The views or opinions presented in this document are solely those of the author and do not necessarily represent those of Durotech Industries, except where the sender expressly, and with clear authority, states them to be the views of Durotech Industries. Durotech Industries accepts no liability for any loss or damage (direct or indirect or consequential) arising from the use of or in connection with this document and any attacchments and suggests that the recipient check this document and any attached files for the presence of viruses."

and dress up to penetrations and down into waste outlets. To joins in sheet flooring, tape and bandage over the PU sealant joint. Cut out cracks in concrete to 6mm minimum width by 6mm minimum depth and fill with PU sealant before application of the membrane.

APPLICATION

To the prepared surface, apply DUROPROOF[™] PPM STD by notched squeegee, spreader, brush or roller within a maximum of 48 hours between coats to achieve an optimum intercoat bond. Turn membrane up at walls and penetrations and down into drainage outlets. When dry, check for pinholes or misses and rectify if necessary. If membrane becomes dirty between coats, clean with Xylene to ensure adhesion. Allow 24 hours to dry before covering.

PRECAUTIONS

Do not apply above 30°C or below 5°C ambient temperature. If applying more than one coat externally, ensure before starting the job, that rain is not expected between coats. Do not apply mortar beds until the membrane is fully dry. Protect membrane against damage before and during covering with mortar. Protect membrane against the action of roots.

WARNINGS AND HAZARDS

Keep away from heat and flame. Use only with adequate

HANDLING AND STORAGE

DUROPROOF[™] PPM STD can be stored for 6 months below 25°C. Avoid prolonged exposure to humidity or high temperature, contamination with water or alcohols. The product is very sensitive to air and moisture. Once opened, use completely as soon as possible and do not reseal for future use.

Durotech Industries Pty Ltd

Address	14 Essex Street, P.O Box 5092, Minto,
	NSW 2566
Phone	+61 2 9603 1177
Fax	+61 2 9475 5059
Email	sales@durotechindustries.com.au
Web	www.durotechindustries.com.au



